

Data Sheet

Part Number: SF4306

Description

The SafeFlame Flame Detector Test Lamp is a Point-And-Use testing device for both UV/IR and IR3 Flame SafeFlame Detectors. Simply point at your SafeFlame Detector and activate to test your detectors without the use of an open flame.

Instructions

1. Turn the test lamp toward the flame detector
2. Press the operation switch (ON)[Check the LED is flashing]
3. Point the brightest part of the lamplight towards the sensor
4. Wait for the flame detector to operate
5. If the flame detector is not working properly, adjust the distance and angle, and then repeat the steps 1 to 4
6. Press the operation switch (OFF)
7. Charge Unit for future use



Specifications

Coverage:	~5m
Weight:	3.5kg
Continuous Operation:	~8hrs
Enclosure:	Aluminum
Usage temperature range:	-20°~50°

For Use With:

SAFE Flame™



Triple IR



UV/IR



Safe Fire Detection, Inc.
5915 Stockbridge Drive
Monroe, NC 28110
Phone: 704-821-7920
Fax: 704-821-4327
www.safefiredetection.com

This document is provided for informational purposes only and may not be reproduced in whole or part without express written permission from Safe Fire Detection, Inc. Safe Fire Detection, Inc. assumes no responsibility for the products suitability for a particular application. Specifications, designs and any information contained herein may change without notice.